

**Download on iTunes
and Google Play**



Smartphone / Tablet Application:

The mobile application telemetry page allows for monitoring of battery and some remote control of power output of the battery.

Monitoring of battery:

1. Battery Internal Voltage - battery cell total voltage
2. Battery Terminal Voltage - voltage that is available at (+) terminal of battery
3. Battery Capacity - displays battery capacity level (displayed in % and actual levels).
4. Power OFF mode status - indicates whether battery is ON or OFF.
5. Battery/Smartphone device connection status - Green LED displayed for connection.
6. Battery Temperature - shows temperature of battery in metric or imperial mode.
7. Module Voltage - display of internal voltage of battery module.
8. Module Current - display of module charging or discharging.
9. Module temperature - display of module temperature.
10. Module Capacity - display of current capacity of module.

Remote Control of battery (controls all modules):

1. Low Power Mode - enable or disable mode.
2. One Last Start Mode - enable or disable mode.
3. Power OFF Mode - enable or disable mode.
4. Heater On Mode - enable or disable mode.